

## MINIMUN INSTALLATION CLEARANCES TO ADJACENT CONSTRUCTION

RIGHT SIDE	32	(81.28)
LEFT SIDE	24	(60.96)
FRONT	24	(60.96)
REAR	24	(60.96)
TOP	24	(60.96)

## NOTES:

- 1. ALL DIMENSIONS SHOWN ARE IN INCHES (CENTIMETERS)
- 2. STANDARD CONNECTIONS:
  - WATER AND AIR INTAKE COMPONENTS/CONNECTIONS ARE ON THE LEFT HAND SIDE ONLY.
  - VENT FLUE ON THE RIGHT HAND SIDÉ. FOR ALTERNATE LOCATIONS AS SHOWN WITH DOT LINES, USE 32"(81.28) FOR VENT FLUE AT ANY SIDE AS NEED AND 24"(60.96) ALL OTHERS.
- 3. WHEN USING THE AERCO CONDENSATE NEUTRALIZER TANK, FOR PROPER CONDENSATE DRAINAGE, THE NEUTRALIZER TANK MUST BE INSTALLED IN A PIT OR THE BOILER AND THE AERCO CONDENSATE TRAP MUST BE ELEVATED HIGHER THAN 4" ABOVE THE FLOOR. SEE CONDENSATE TANK INSTRUCTIONS TID-0074 FOR DETAILS.



100 ORITANI DRIVE BLAUVELT, NY 10913 aerco.com

MODULEX EXT 1500-3000/1530-3060 MBH GAS FIRED BOILER SINGLE UNIT INSTALLATION CLEARANCE

DWN.BY _	<u>K.S.</u> <sub>D</sub>	ATE <u>080813</u>
SCALE _	NTS_	
REV.DATE		020717

SD-A-982 B