

Maintenance and Preventative Kits

Modulex and Modulex EXT

Modulex EXT

To ensure continued safe, reliable, and efficient operation of your Modulex EXT boiler, regular maintenance and inspection must be performed in accordance to the user manual. AERCO offers a complete line of maintenance kits and fireside inspection kits.

- The Maintenance Kits consist of the spark ignitor and flame detector (with gaskets) for each module
- The Fireside Inspection Kits consist of the spark ignitor, flame detector, and burner gasket for each module.

Note: The Fireside Inspection Kit already includes the components included in the Maintenance Kit - therefore, when performing the Fireside Inspection, you only need the Fireside Inspection Kit, not both.



- Maintenance Kits: 30-90 minutes (dependent on boiler size)
- Fireside Inspection Kits: 1-3 hours (dependent on boiler size)



Typical components of a Maintenance Kit



Typical components of a Fireside Inspection Kit

For further information visit aerco.com.



Kit Type	Part #
MLX EXT 321 Maintenance Kit	58086-01
MLX EXT 481/450 Maintenance Kit	58086-02
MLX EXT 641/600/1530/1500 Maintenance Kit	58086-03
MLX EXT 802/800/1912 Maintenance Kit	58086-04
MLX EXT 962/2295/2300 Maintenance Kit	58086-05
MLX EXT 1123/1100/2677/2600 Maintenance Kit	58086-06
MLX EXT 3060 Maintenance Kit	58086-11
MLX EXT 321 Fireside Inspection Kit	58086-12
MLX EXT 481/450 (2S) Fireside Inspection Kit	58086-13
MLX EXT 641/600 (2S) Fireside Inspection Kit	58086-14
MLX EXT 802/800 (2S) Fireside Inspection Kit	58086-15
MLX EXT 962 (2S) Fireside Inspection Kit	58086-16
MLX EXT 1123/1100 (2S) Fireside Inspection Kit	58086-17
MLX EXT 1530/1500 (2S) Fireside Inspection Kit	58086-18
MLX EXT 1912 Fireside Inspection Kit	58086-19
MLX EXT 2295/2300 (2S) Fireside Inspection Kit	58086-20
MLX EXT 2677/2600 (2S) Fireside Inspection Kit	58086-21
MLX EXT 3060/3000 (2S) Fireside Inspection Kit	58086-22

Modulex

To perform the necessary tasks indicated in the maintenance schedule of the Modulex O&M, AERCO offers a complete line of maintenance kits and fireside inspection kits.

- The Maintenance Kits consist of the spark ignitor and flame detector (with gaskets) for each module.
- The Fireside Inspection Kits consist of the spark ignitor, flame detector, and burner gasket for each module, flue collector gasket, and exhaust connector gasket.

Note: The Fireside Inspection Kit already includes the components included in the Maintenance Kit - therefore, when performing the Fireside Inspection, you only need the Fireside Inspection Kit, not both.



- Maintenance Kits: 30 minutes
- Fireside Inspection Kits: 1-3 hours (dependent on kit)

For further information visit aerco.com.

Kit Type	Part Number
MLX-303 Maintenance Kit	58019-01
MLX-454 Maintenance Kit	58019-02
MLX-606 Maintenance Kit	58019-03
MLX-757 Maintenance Kit	58019-04
MLX-909 Maintenance Kit	58019-05
MLX-1060 Maintenance Kit	58019-06
MLX-303 Fire Inspection Kit	58019-07
MLX-454 Fire Inspection Kit	58019-08
MLX-606 Fire Inspection Kit	58019-09
MLX-757 Fire Inspection Kit	58019-10
MLX-909 Fire Inspection Kit	58019-11
MLX-1060 Fire Inspection Kit	58019-12



Typical components of a Maintenance Kit



Typical components of a Fireside Inspection Kit

