

BE 6" AWAY FROM SIDE PANELS.

5) THIS IS A TYPICAL INSTALLATION DRAWING. LOCAL CODES AND AUTHORITIES SHOULD BE CONSULTED.

ELECTRIC CONNECTIONS (SERVICE SWITCHES, CONDUIT BOXES) SHOULD LIKEWISE

6) WHEN USING THE AERCO CONDENSATE NEUTRALIZER TANK, FOR PROPER CONDENSATE DRAINAGE, THE NEUTRALIZER TANK MUST BE INSTALLED IN A PIT <u>OR</u> THE BOILER AND THE AERCO CONDENSATE TRAP MUST BE ELEVATED HIGHER THAN 4" ABOVE THE FLOOR. SEE CONDENSATE TANK INSTRUCTIONS TID—0074 FOR DETAILS.

AERCO INTERNATIONAL, INC. 07647

BENCHMARK 3 MIL. BTU LOW NOX
GAS FIRED BOILER LAYOUT—COMBINATION
HEATING & DOMESTIC WATER PLANT

DWN.BY CZ DATE 072606		REV.
SCALE APPDMC_ DATE	SD-A-685	В